



### TIME MODE

- Alarm 1 / Alarm 2 / Alarm 1 & 2 / Alarms Off
- Set alarms
- Radio on / Radio off
- Enter time settings

### ALARM SOUNDING:

- Start snooze cycle (9 min)
- Cancel snooze
- Cancel alarm

### ALARM SET

- Enter Alarm Settings
- Select Alarm (AL1 / AL2)
- Select (Everyday / Weekdays / Weekends)
- Change Hours (HH)
- Change Minutes (MM)
- Select Buzzer (🔔) or Radio (🎵)
- Select Volume Level Return to current mode

### TIME SET

- Enter Time Settings
- Select Day
- Select (24H / 12H)
- Change Hours (HH)
- Change Minutes (MM) Return to current mode

### RADIO MODE

- Starts last FM frequency - after 10sec displays time
- Tune FM frequency
- FM auto tuning
- Stop radio & return to time mode

### SLEEP MODE

- Enter sleep timer
- Cycle between (Off / 10 / 20 / 30 / 45 / 60 / 90 / 120min)
- Select sleep time, radio fades to off at end of timer

### PRESETS

- Recall presets
- Select a preset
- Wait 5sec to exit
- Save presets
- Select a preset
- Wait 5sec to exit



Scan for full instructions  
 Consultez les instructions complètes  
 Scannen für die vollständige Anleitung  
[www.robertsradio.com](http://www.robertsradio.com)  
 © 2022 Roberts Radio Limited