


Mon Days of Week
 Buzzer Alarm On/Off
 Radio Alarm On/Off

zz Snoozing
 Sleep Timer
 PM 12h Mode
 FM FM Radio



TIME MODE

- [Bell icon] Alarm 1 / Alarm 2 / Alarm 1 & 2 / Alarms Off
- [Bell icon] 2 sec Set alarms
- [S] Radio on / Radio off
- [S] 2 sec Enter time settings

ALARM SOUNDING:

- [S] Start snooze cycle (9 min)
- [S] Cancel snooze
- [Bell icon] Cancel alarm

ALARM SET

- [Bell icon] 2 sec Enter Alarm Settings
- [S] Select Alarm (AL1 / AL2)
- [S] Select (Everyday / Weekdays / Weekends)
- [S] Change Hours (HH)
- [S] Change Minutes (MM)
- [S] Select Buzzer (Bell) or Radio (Musical notes)
- [S] Select Volume Level Return to current mode

TIME SET

- [S] 2 sec Enter Time Settings
- [S] Select Day
- [S] Select (24H / 12H)
- [S] Change Hours (HH)
- [S] Change Minutes (MM) Return to current mode

RADIO MODE

- Starts last FM frequency - after 10sec displays time
- [S] Tune FM frequency
- [S] 2 sec FM auto tuning
- [S] Stop radio & return to time mode

SLEEP MODE

- [S] 2 sec Enter sleep timer
- [S] Cycle between (Off / 10 / 20 / 30 / 45 / 60 / 90 / 120min)
- [S] Select sleep time, radio fades to off at end of timer

PRESETS

- [Heart icon] Recall presets
- [S] Select a preset
- Wait 5sec to exit
- [S] 2 sec Save presets
- [S] Select a preset
- Wait 5sec to exit



Scan for full instructions
 Consultez les instructions complètes
 Scannen für die vollständige Anleitung
www.robertsradio.com
 © 2022 Roberts Radio Limited